



Residential

RESIDENTIAL PATIO AWNING

An optional deck plate kit is available for the Residential Awning. These plates can be mounted onto the patio surface to provide secure attachment for the patio arms when used in the vertical position.

INSTALLATION

1. Extend the awning out completely.
2. Follow the instructions for placing the arms in the vertical support position. Refer to the awning owner's manual.
3. Mark the position of the foot on the patio surface.
4. Move the arm out of the way.
5. Position the deck plate over the marks. Mark the location of the mounting screws. Then drill a 3/16" pilot hole for each mounting screw.
6. Attach the deck plate to the surface using two (2) 1/4 x 1 1/2" flat head screws and washers. The washers go between the deck plate and mounting surface as shown.

NOTE: Screws are furnished for wood decks. If mounting the plates on concrete or similar material, it will be necessary to drill and install the appropriate size anchors. Anchors are not included with the awning.

7. On the arm foot:
 - 7.1. From the top, insert the nuts into the holes of the arm foot. Lightly tap the nuts until flush with the bottom of the foot.
 - 7.2. Screw the 3/8-16 flat head screws into the nuts from the bottom of the foot. Tighten the screws until the heads are 3/16" to 1/4" from the bottom of the foot.
 - 7.3. Repeat for the second awning arm.

TO USE

1. Position the arm in the vertical position.
2. Gently twist the arm so the heads of the flat head screws slide into the large holes in the deck plate.
3. Twist the arm straight. The screw heads then lock under the deck plate.
4. *To release:* Gently twist the arm clockwise and lift the arm from the deck plate.

