

An awning specifically designed for the Over the Door applications

Carefree's Over the Door (OtD) Awnings are a perfect complement for Carefree patio and window awnings.

- OtD awnings provide shade for the door and shields the inside of the RV.
- Carefree offers a wide variety of color fabrics to match existing awnings.

SPECIFICATIONS

WIDTHS: 40" 48" 54" 56" 57" 60" 64" 66" 72"

COLOR: *Hardware:* Satin, White, Black
Fabric: Vinyl, Fullview or Acrylic
Fabric Wrap: Vinyl Weatherguard (vinyl only)
Alumaguard

MEASURING TIPS:

- OtD awning rail must be mounted a minimum of 11" above the door to provide proper clearance.
- Requires a flat unobstructed mounting surface with a minimum of 2" wide x 62" tall for proper mounting.
- Curved arm measurements are center of top plug to center of top plug.
- Straight-arm measurements are center of arm to center of arm.
- Fabric will measure 6" less than the size ordered.
- Bottom bracket measures 1" wide x 2 ½" tall.
- Curved arm OtD awnings are for specific coach applications, insure the rear arm has an unobstructed mounting space without interference from lights, vents or other awnings.



CURVED ARM APPLICATION CHART

Coachmen Destiny	96' & newer	Newmar Mountain Aire	96' & newer
Fleetwood Discovery	2000 model	Newmar Dutch Star	96' & newer (front door models)
Harney Renegade	99' & newer	Safari Continental	96' & newer
Holiday Rambler Endeaver	98' & newer	Safari Serengeti	96' & newer
Monaco Diplomat	ALL	Safari Sahara	96' & newer
Monaco Dynasty	95' & newer	Tiffan Allegro Bus	97' & newer
Monaco Windsor	ALL (front door models)		

ORDERING:

You will need to know the following information:

- Length of awning.
- Straight or Curved Arm application and color.
- Choice of fabric, weatherguard or Alumaguard.
- All orders are custom and Non-Returnable.

SHIPPING:

- Applicable freight charges apply.

ON-LINE AT WWW.CAREFREEOFCOLORADO.COM

- ◆ Product Manuals
- ◆ Fabric Options
- ◆ Warranty Information